

## TKlamp Lighting Tester Docs

TKlamp Flashlight Tester is a specialized lighting meter designed to measure lumen, candela and lux values of flashlights.

The TK2303D model offers data logging capabilities, allowing users to transfer measurement data to a PC for further analysis. This repository contains a quickstart guide to exporting data from TK2303D, a detailed user manual and serial data specifications.

If you are instead looking for:

TKlamp Lighting Testers, visit [website](#).

Purchasing TKlamp Tester, visit [online store](#).

## Documentations

1. Data Logging Tutorial - Quickstart guide to exporting data to PC
2. User Manual
3. Serial Data Specifications - How to interpret raw serial data from UBS serial port

## Contributing

To make contributions, join [Discord](#).

To suggest any changes in the repos, use [pull request](#) or [Discord](#).

## TK2303D Specifications

### Table of Content

- Measurements & Range
- Resolution
- Live Plotting
- Sensor sampling time interval
- Lux and Candela Measurement
- Wavelength
- Data Logging and Transfer
- Timer
- Power Supply

- Dimensions

## Measurements & Range

- Luminous flux. Range: 0-25,000 lm
- Luminous intensity. Range: 0-6,500,000 cd
- Illuminance. Range: 0-250,000 lux

## Resolution

- Live reading and plotting: 1lm/1cd/1lux
- Data logging: 1lm. cd and lux x1/x10/x100

Select cd/lux multiplier in settings based on estimated value:

- cd/lux < 65,535: select x1. (Max value: 65,535. Resolution 1 cd/lux)
- 65,535 ≤ cd/lux < 655,350: select x10 resolution (Max value: 655,350. Resolution 10 cd/lux )
- cd/lux ≥ 655,350: select x100 resolution (Max value: 6,553,500. Resolution 100 cd/lux)

This is because log data is stored and transferred in 2 bytes, which can only represent up to 65,535 in value.

## Live Plotting

- Lumen/Candela/Lux each has 600 sampling data points
- Sampling time: adjustable between 0.2s - 60.0s
- Maximum logging time: 600 mins (10 hrs)

## Sensor sampling time interval

- Sensor sampling time interval: 150ms
- Sampling rate: ~6.6 times per second.

## Lux and Candela Measurement

- Distance to surface range: 1-10m
- External sensor cable length: 2m
- External sensor extension cable length: 10m (Not included. Can be purchased separately)

## Wavelength

- Range: 450-650nm (Not for UV/IR light)

## Data Logging and Transfer

- Data length: 3620 bytes
- Data transfer time: approx. 5s
- Communication interface: RS485 USB

## Timer

- Up timer: up to 24 hours
- Down timer: 1-999 minutes


## Power Supply

- Power consumption: < 4w
- AC power/DC power
- AC power range: 90~240V
- DC power range: 5~24V


## Dimensions

- Sphere opening sizes: 0.7", 1.5", 2.9"
- Sphere diameter: 6.29"


### Home Screen




### Lumen Measurement



## Lux/Candela Measurement



## Data Plotting and Logging



Data Transfer

Data Transfer

Data transfer starting in 10s.  
Please start the receiving program on  
he computer

8S

EXIT

Data Transfer

Transfer complete.

3620 bytes transferred

EXIT

Settings

Always remember to save any changes before exiting settings

Distance from external sensor to light source.  
Range: 1-10 meters

Set distance to surface (1.00~10.00 m)

5.00

Click to set

SAVE

Set data logging sampling time.  
This differs from measurement sampling time.  
Range: 0.2 - 60 seconds

Set sampling time (200~60000 mS)

1000

Click to set

SAVE

Set down timer duration.  
Range: 1-999 minutes

Set timer duration (1~999 min)

99

Click to set

SAVE

Select cd/lux multiples based on estimated value

Adjust cd/lux multiples (x1 x10 x100)

cd

lux

x 100

x 10

SAVE

- cd/lux < 65,535: select x1. (Max value: 65,535. Resolution 1 cd/lux)
- 65,535 ≤ cd/lux < 655,350: select x10 resolution (Max value: 655,350. Resolution 10 cd/lux)
- cd/lux ≥ 655,350: select x100 resolution (Max value: 6,553,500. Resolution 100 cd/lux)

Any changes in multiples will clear the current data plotting and logging

Serial Data Reference

This reference is created for decoding raw serial data read directly from USB serial port or 3rd party application such as CoolTerm.

To see a sample serial data output, click [here](#). The same data is used in the examples below.

Total length: **3620 bytes**

- Header: 1-16 bytes

- Body: 17-3616 bytes
- Ending: 3616-3620 bytes

## Table of Content

- Header
- Body
- Ending

## Header

```
1 <table>
2   <tr>
3     <th>Byte position</th>
4     <td>1-2</td>
5     <td>3-4</td>
6     <td>5-6</td>
7     <td>7-8</td>
8     <td>9-10</td>
9     <td>11-12</td>
10    <td>13-14</td>
11    <td>15-16</td>
12  </tr>
13  <tr>
14    <th>Example data</th>
15    <td>aa aa</td>
16    <td>0e 10</td>
17    <td>01 f4</td>
18    <td>00 64</td>
19    <td>00 01</td>
20    <td>00 01</td>
21    <td>00 01</td>
22    <td>56 44</td>
23  </tr>
24  <tr>
25    <th>Explanation</th>
26    <td>Start indicator</td>
27    <td>Data body length (3600 bytes fixed) </td>
28    <td>Sampling time</td>
29    <td>Distance to surface</td>
30    <td>Lumen multiples</td>
31    <td>Candela multiples</td>
32    <td>Lux multiples</td>
33    <td>Version</td>
34  </tr>
35 </table>
```

## Body

```

1 <table>
2   <tr>
3     <th>Byte position</th>
4     <td>17-1216</td>
5     <td>1217-2416</td>
6     <td>2417-3616</td>
7   </tr>
8   <tr>
9     <th>Example data</th>
10    <td>44 00 .. .. 00 00 </td>
11    <td>00 00 .. .. 00 00 </td>
12    <td>75 00 .. .. 00 00</td>
13  </tr>
14  <tr>
15    <th>Explanation</th>
16    <td>Lumen (each data point is 2 bytes) </td>
17    <td>Candela (each data point is 2 bytes) </td>
18    <td>Lux (each data point is 2 bytes) </td>
19  </tr>
20 </table>

```

- TK2303D tester can take 600 sample points. Each sample point consists of 2 bytes.
- Lumen, Lux and Candela each has  $600 * 2 = 1200$  bytes data total.
- Data persists time ascending order.

## Ending

```

1 <table>
2   <tr>
3     <th>Byte position</th>
4     <td>3617-3618</td>
5     <td>3619-3620</td>
6   </tr>
7   <tr>
8     <th>Example data</th>
9     <td>ee ee</td>
10    <td>1a b0</td>
11  </tr>
12  <tr>
13    <th>Explanation</th>
14    <td>Ending indicator </td>
15    <td>No meaning</td>
16  </tr>
17 </table>

```